

Charging Procedures and FAQs for VorzAMP Pure II

To charge your amplifier properly:

- Switch OFF Amplifier
- AC Charger output must be 5V DC minimum 1A or Notebook/computer USB to have minimum current of 1A

FAQs

1	At the start of charging the amplifier the Red LED light is blinking	Charging rate is not optimal: <ul style="list-style-type: none">• Switch OFF the amplifier• AC charger is incorrect (current must be minimum 1A)• USB port of Notebook/computer current too low (current must be minimum 1A)
2	Can the amplifier be playing and at the same time be charging?	<ul style="list-style-type: none">• Yes, but the charging rate will be slow and the amplifier will not be able to be Fully Charged.• The Red LED light will blink after 3h to 3.5h (switch OFF AC charger for 5 seconds and turn it ON again)• If you need to charge and play the amplifier at the same time, first charge the amplifier for 1h before playing/using the amplifier.
3	How do I know the amplifier is Fully charged?	<ul style="list-style-type: none">• During charging the Red LED light will turn OFF automatically. (~3.5h)
4.	After charging for more than 3h the Red LED starts blinking.	<ul style="list-style-type: none">• The internal charging time has exceeded, switch Off the AC charger for a few seconds and turn On again.• It is recommended that the amplifier is switched OFF while charging, to give it a quick and full charge.